



F16. 2

MEASURE COMMUNICATION CONDITION INDICIA LEVEL UPON THE FORWARD LINK FORM A FIRST CHANNEL 86 CONDITION INDICIA VALUE SELECT A FIRST DATA -88 RATE HON WHICH TO SEND SUBTEQUENT DATA FORM A FIRST DATA 92 RATE SELECTION VALUE SEND FIRST DATA RATE SELECTION VALUE TO NETWORK DETECT FIRST DATA RATE SELECTION VALUE SELECT PONER LEVEL AT WHICH TO SEND DATA

F16.3